




JWL Brake Bleeder is easy to use for one person. Comes with or without replenishment system. Can also be used for MC.



Materials

Handle and trigger	Acetal plastic
Valve	Acetal plastic
Gaskets/O-rings	EPDM
Springs	Hardened spring wire
Containers	PEHD
Hoses	PVC
Rubbernozzles	TPU

Technical description

Working pressure	6-12 bar (87 -174 psi)
Air consumption	Max. 180 l/min. at 8 bar
Container	1.2 L
Vacuum	min. 60 %
Thread	BSP/NPT

Brake Bleeder

JWL Brake Bleeders are used for quickly bleeding and refilling the brake systems of all types of vehicles. It can be operated by a single person. Brake bleeding is completed quickly, clean and simple. Brake fluid is pulled into the container avoiding spillages.

JWL Brake Bleeders are available in several models: with or without refilling systems, for cars and motorcycles and with or without safety valve, that prevents the fluid to atomize when the container is full. JWL Brake bleeders must never be used for explosive fluids, e.g. petrol and acetone.

JWL Brake Bleeders are approved and distributed by leading brake disc manufacturers.



How to use

With JWL Brake Bleeder, one person can carry out the bleeding of the brake systems.

DO NOT TOUCH THE BRAKE PEDAL WHILE BLEEDING THE BRAKES.

NOTE: MAINTENANCE AND CLEANING AFTER USE IS RECOMMENDED.

1. Connect the gun to the compressed air system.
2. Set the brake bleeder's rubber pipe on the brake system plug, and loosen the plug.
3. Activate the handle of the brake bleeder, a partial vacuum is created in the brake bleeder container, and the fluid is sucked into the container.
4. When the brake fluid is free of air bubbles, which can be seen through the clear hose, then tighten the bleeding plug and remove the rubber pipe.
5. Repeat the procedure for each brake calliper.
6. REMEMBER to check the fluid level.

JWL Brake Bleeders

Art. No.



JWL Brake Bleeder with 1.2 L container.

143102-000

JWL Brake Bleeder with 1.2 L container and safety valve.

143103-000



JWL Brake Bleeder with replenishment system and 1.2 L container.

143112-000


JWL Brake Bleeder with replenishment system, 1.2 L container and safety valve.

143113-000



JWL Brake Bleeder for MC with 1.2 L container.

143123-000



Safety valve. Suitable for all JWL Brake Bleeder models. The safety valve prevents the fluid to atomize when the container is full.

143267

Accessories

Art. No.

Container 1.2 L

143300

Container with lid 1.2 L

143160

Repair kit: hose, hose connectors, rubber pipe relief spring and O-ring

143155

Repair kit (MC): Y-piece, hose, hose connection, rubber pipe, hose relief & O-ring

143156

Silencer

143802-711

Rubber pipes (5-pack)

143166-000

O-rings (5-pack)

143164-000

Y-piece for MC

143804

Replenishment system

143150